Clippard

PIV Series PEEK Media Isolation Valves



- Low power consumption
- Multiple Pressure Range Options
- Bidirectional
- Minimal dead volume
- All wetted areas PEEK body and PTFE diaphragm
- · Ideal for use with corrosive media
- High cycle life
- Fast response time
- CE, RoHS Compliant
- Low leak design
- Custom body, materials, threads and pressures
 available
- Proudly Made in USA. ISO 9001



The Clippard PIV Series Media Isolation Valve is a solenoid-

operated device that uses a flexible diaphragm to isolate the actuation mechanism from the fluid path. Media isolation valves are commonly used for a wide variety of applications, including those that require precise, repeatable dispensing of media for analytical instrumentation. All wetted areas of the valve are PEEK body and PTFE diaphragm, making this series ideal for use with corrosive media.

A unique feature of the PIV Series is the one-piece valve stem that functions as a sealing membrane while also supporting and centralizing the poppet in the seating area. This multi-functional poppet/diaphragm/stem results in a simplified design with fewer parts (only two for the 2-Way and three for the 3-Way), longer life and minimal dead volume. Choose from four orifice sizes available as 2-Way Normally-Closed, 2-Way Normally-Open, or 3-Way Selector/Diverter. Special configurations available by request.

Industries and applications that commonly use these types of valves to isolate gas or liquid include: drug dispensing, laboratory equipment, analytical, chemical analysis, sampling, life science/biotech, genetic research, gas chromatography, spectrometry, DNA synthesizing, blood analyzing, printing, diagnostic equipment, fermentation, water treatment and more.

SPECIFICATIONS

Valve Function	2-Way Normally-Closed, 2-Way Normally-Open, 3-Way Selector/Diverter
Medium	Air, water, gas, or compatible fluids
Operating Temperature	158°F (70°C)
Operating Pressure	Vac. to 30 psig (2 bar) or 100 psig (6.9 bar) (additional options available*)
Flow Rate	6 to 60 l/min. air @ 30 psig
Wattage	1.0 to 7.2 watts
Response Time	5 to 20 ms typ.
Connector	18" wire leads (45 cm)
Voltage	12 or 24 VDC (additional options available*)
Ports	#10-32, 1/4-28 UNF or 1/8 NPS
Mount	#2-56 or #4-40
Material, Wetted	PEEK (PTFE diaphragm and PPS body also available*)

Read more online at <u>clippard.com/link/piv</u>

* Contact Clippard for additional information



877-245-6247 | clippard.com

DRAWINGS

					Dimensions—See Figures 1-4, below				Part Number			
Туре	Orifice	Flow @ 30 psig	Ports	Fig.		В	C	D	E	G	12 VDC	24 VDC
2-Way, Normally- Closed	0.040″	6 l/min	#10-32	1	0.750″	1.155″	0.500″	#2-56 x 0.094″ deep	0.363″	n/a	NR1-2-12-P/H	NR1-2-24-P/H
	0.062″	16 l/min	1/4-28	3	1.000″	1.488″	0.687″	#4-40 x 0.125″ deep	0.450″	n/a	NR2-2-12-P/H	NR2-2-24-P/H
	0.093″	38 l/min	1/4-28	3	1.250″	1.863″	0.884″		0.500″	1.500″	NR3-2-12-P/H	NR3-2-24-P/H
	0.156″	60 l/min	1/8 NPS	3	1.500″	2.088″	1.125″		0.562″	1.750″	NR4-2-12-P/H	NR4-2-24-P/H
2-Way, Normally- Open	0.040″	6 l/min	#10-32	1	0.750″	1.163″	0.500″	#2-56 x 0.094 deep	0.363″	n/a	NR1O-2-12-P/H	NR1O-2-24-P/H
	0.062″	16 l/min	1/4-28	2	1.000″	1.493″	0.687″	#4-40 x 0.125″ deep	0.450″	n/a	NR2O-2-12-P/H	NR2O-2-24-P/H
	0.093″	38 l/min	1/4-28	4	1.250″	1.814″	0.884″		0.500″	1.500″	NR3O-2-12-P/H	NR3O-2-24-P/H
	0.156″	60 l/min	1/8 NPS	4	1.500″	2.039″	1.125″		0.562″	1.750″	NR4O-2-12-P/H	NR4O-2-24-P/H
3-Way, Selector/ Diverter	0.040″	6 l/min	#10-32	1	0.750″	1.161″	0.500″	#2-56 x 0.094" deep	0.363″	n/a	NR1-3-12-P/H	NR1-3-24-P/H
	0.062″	16 l/min	1/4-28	2	1.000″	1.492″	0.687″	#4-40 x 0.125″ deep	0.450″	n/a	NR2-3-12-P/H	NR2-3-24-P/H
	0.093″	28 l/min	1/4-28	4	1.250″	1.814″	0.884″		0.500″	1.500″	NR3-3-12-P/H	NR3-3-24-P/H
	0.156″	60 l/min	1/8 NPS	4	1.500″	2.039″	1.125″		0.562″	1.750″	NR4-3-12-P/H	NR4-3-24-P/H



ORDERING INFORMATION

Unit	Orifice - Ports - Flow @ 30 psig	Function	Voltage	Operating Pressure
Imperial	NR1 0.040" - #10-32 - 6 l/min NR2 0.062" - 1/4-28 UNF - 16 l/min NR3 0.095" - 1/4-28 UNF - 38 l/min NR4 0.156" - 1/8" NPS - 60 l/min	-22-Way Normally-ClosedO-22-Way, Normally-Open-33-Way Fully-Ported	-12 12 VDC -24 24 VDC	-P Vac. to 30 psig -H Vac. to 100 psig
Example Part	No. NR2-2-12-P			

On-Line Configurator Available

Solenoid-Operated PTFE Media Gradient Isolation Valves



Mixing isolation valves combine multiple solenoids into a single compact unit. The valve incorporates up to six separate sources of media into one stream that is integral to a single block. They feature independent

inlets and one common outlet, or one common inlet and multiple independent outlets. Compatible with corrosive and aggressive medium, these valves are useful for solvent selection, stream splitting, flushing, mixing, diverting, blending, indexing and other automated applications.

.

Read more online at cippard.com/link/nivg

ADDITIONAL RESOURCES AVAILABLE ONLINE AT CLIPPARD.COM

- 2D & 3D files
- Product configurators
- Calculators
- Videos, white papers & more
- Download Clippard's Full-Line Product Catalog
- Locate your nearest Clippard Distributor
- Request Technical Help

PROFESSIONALLY DISTRIBUTED BY:

<text><text><text><text><text><text><text><text>



877-245-6247 | clippard.com

Solenoid-Operated & Pneumatic Pinch Valves



Pinch valves are an excellent alternative to traditional mechanical valves when media contamination is a concern, as they interact with medical grade tubing, and never touch the material being

dispensed. Clippard's compact NPV series offers four styles with multiple size, tubing and pressure options making them ideal for pharmaceutical, laboratory, wastewater, medical, and chemical industries, among others. Features include high flow, low power consumption, high cycle life, quick response and more.

Read more online at clippard.com/link/npv